

4NKT 0603


Indexable Compability: TT



Item Code	Stock		Dimension mm					Spare Parts		
	Stock	Inter C	D	Z	L1	L	d	Insert	Screw	Torx
HEI.1093700	•	◦	16	2	40	120	16	4NKT 0603	M3X8	T10
HEI.1093800	•	•	16	2	50	150	16	4NKT 0603	M3X8	T10
HEI.1093900	•	•	17	2	30	150	16	4NKT 0603	M3X8	T10
HEI.1094000	•	•	17	2	30	200	16	4NKT 0603	M3X8	T10
HEI.1094100	•	•	20	3	50	160	20	4NKT 0603	M3X8	T10
HEI.1094200	•	•	21	3	30	200	20	4NKT 0603	M3X8	T10
HEI.1094300	•	•	25	3	60	200	25	4NKT 0603	M3X8	T10
HEI.1094400	•	•	26	3	30	200	25	4NKT 0603	M3X8	T10
HEI.1094500	•	◦	25	3	40	120	25	4NKT 0603	M3X8	T10
HEI.1094600	•	•	20	3	40	120	20	4NKT 0603	M3X8	T10
HEI.1094700	•	◦	20	2	40	160	20	4NKT 0603	M3X8	T10
HEI.1094701	•	•	25	3	40	150	25	4NKT 0603	M3X8	T10
HEI.1608900	•	•	25	4	40	150	25	4NKT 0603	M3X8	T10
HEI.1609000	•	•	18	2	30	150	16	4NKT 0603	M3X8	T10
HEI.1609100	•	•	22	3	30	160	20	4NKT 0603	M3X8	T10
HEI.1609200	•	•	21	3	30	160	20	4NKT 0603	M3X8	T10

6NGU 0604

Indexable Compability: TT



Item Code	Stock		Dimension mm					Spare Parts		
	Stock	Inter C	D	Z	L1	L	d	Insert	Screw	Torx
HEI.1365400	•	•	25	2	50	150	25	6NGU 0604	M3X8	T10
HEI.1385900	•	•	32	3	50	150	32	6NGU 0604	M3X8	T10